


Pallet changer Pal system


Pal system capable of changing pallets while maintaining hydraulic clamp in clamp condition

Non-leak coupler fitting stroke 4 mm




Select one of either spring clamp (model CPC) or hydraulic clamp (model CPH).

Pallet - unclamping & coupler disconnected



In pallet-unclamp, coupler disconnects due to lift stroke of pallet changer, with hydraulics sustained.

Pallet - clamping & coupler connected



In pallet-clamp, coupler connects due to clamp stroke of pallet changer, with hydraulics sustained.