


Caution in Use

Hose system


- Hose should have a sufficient length with margin (it is advised to have 10 or 20 % of margin on top of the overall length of piping).




- Be sure to use hose clips to avoid the abrasion by contacting the sharp edges in the die. The hose is wobbled by not only stamping vibration but also the pulse of gas-charge.



- Carry out the piping installation without twisting hoses.



- Piping should not be done with smaller bending radius than the minimum bending radius (R20).



- When using a long hose, use a hose clip to fix the hose at the die side to avoid an effect from vibration.



- Choose an adequate hose nut model to avoid bending the hose at sharp angle.

